

| Date | Project | |
|------|-------------|--|
| Туре | Part Number | |



ALL-IN-ONE PERFORMANCE LIGHTING

T8 Series

4ft Bypass Ballast LED T8 Tube

Ballast Bypass T8 Tubes are designed for direct wiring, eliminating the need for a ballast. These energy-efficient bulbs offer superior brightness, long-lasting performance, and easy installation. Ideal for retrofit projects, they reduce maintenance and energy costs while providing flicker-free, high-quality illumination.



PRODUCT FEATURES

- Built-in safety switch prevents electrical shock during installation
- Operates directly on 120-277V & 347V line voltage
- Compatible with shunted and non-shunted lamp holders
- Rated for use in fully enclosed fixtures.
- Suitable for use in dry and damp locations
- NSF Listed: NSF/ANSI Standard 2 Food Equipment
- Operating Temperature: -4°F to 113°F (-20°C to 45°C)
- 120V TRIAC Dimming
- Reno LED T8 lamps conform to UL 1598 Standard

905-604-4666

10 year limited warranty

KEY SPECIFICATIONS

| Voltage | 120-347V | | |
|----------------------|---|--|--|
| Lamp Base | G13 (Medium Bi-Pin) | | |
| Wattage | 13W | | |
| Length | 4FT | | |
| Efficacy | Up to 169 lm/W | | |
| сст | Selectable CCT: 30/35/40/50/6500K | | |
| | | | |
| CRI | >83 | | |
| CRI Lumens | >83 Up to 2,200 lm | | |
| | | | |
| Lumens | Up to 2,200 lm | | |
| Lumens Beam Angle | Up to 2,200 lm 330° Double ended or Single ended power (347V only | | |





SPECIFICATIONS – T8 TYPE B

| Order# | Model | Wattage | Voltage | Lumens | Efficacy | ССТ |
|--------|-----------------------------|---------|----------|----------|----------|-------------------|
| R41140 | RENO-LEDT8-13W-DV-MCCT-48GC | 13W | 120-347V | 2,200 lm | 169 lm/W | 30/35/40/50/6500K |

ACCESSORIES



RENO-S-SN-U-PBT

Shunted T8 Socket

| Model | Description |
|-----------------|-------------------|
| RENO-S-SN-U-PBT | Shunted T8 Socket |





DIMENSIONS









PROTECTION FEATURES

INTERNAL SAFETY SWITCH



Internal Safety Switch for installation protection. (No current will flow until pins on both ends are engaged)

MISUSE PROTECTED FUNCTION



Misuse - Protected function if forgot to by-pass the ballast, the lamp won't work, no risk of fire or cap melting.

DOUBLE-ENDED INSTALLATION

- 1. Cut all existing connections to ballast as shown below and remove ballast. See Figure A above for typical ballast configurations.
- 2. Re-wire fixture as shown below. For Double-ended wiring, use either shunted or nonshunted lampholders. **Note:** There should not be any exposed wires at the end of installation.

