


#### LED BOLLARD FIXTURES

#### INSTALLATION INSTRUCTIONS



1. Open the package. The package contains A and B.



Please read and understand this entire manual before attempting to assemble, operate or install the product.



WARNING: RISK OF FIRE, ELECTRIC SHOCK, INJURY OR PROPERTY DAMAGE.

- 1. Risk of electric shock—Disconnect power to equipment before installing or servicing. This equipment must be installed according to all applicable codes & ordinances.
- 2. Installation and service of this equipment must be performed by qualified service personnel.
- 3. Read these instructions before installing, servicing or maintaining this equipment.
- 4. The installer must ensure that the foundation is stable and can support the luminaire's weight.
- 5. The Installer must use proper means to secure the luminaire to the ground.

#### CAUTION:


- 1. Edges may cut--wear gloves while handling or servicing this equipment.
- 2. Inspect equipment for damage from shipping and handling.
- 3. Recommended cleaning substances: Wipe off dust with a dry, soft cloth. Remove greasy spots etc. with a soft cloth dampened in lukewarm water (<122° F/50° C) with a mild detergent.
- 4. This fixture requires a 120-277Vac power source.
- 5. Operating temperature -40° C to 50° C (-40° F to 122° F).
- 6. Suitable for wet locations.

This device complies with FCC Part 15 Subpart B. Operation is subject to the following two conditions: (1) this device may not cause harmful inference, and (2) this device must accept any inference received, including that

Retain these instructions for future maintenance reference.

## **Bollard Installation**

2. Get the anchor bolt carrier assembled as Fig. 1 and use it to determine placement of anchor bolts in concrete.



4. Using the hex wrench, loosen the 3 screws on the side of the head, and open the top head. Fig. 3

3. Install 3 anchor bolts into concrete as per attached Fig. 2, having at least 1-1/2~2" protruding from concrete with threads free and clear of debris and dirt (Electrical conduit are reserved in the concrete center).





Fig 2

5. Remove the 2# 3/4"plug screws, and select desired wattage & CCT, select desired PC on/off, through the dial swithches on the driver box bottom plate. Fig. 4







## **LED BOLLARD FIXTURES**


## **INSTALLATION INSTRUCTIONS**

6. Put the top head back on and tighten the 3 screws. Fig. 5



Fig 5

7. Using the hex wrench, loosen the 3 screws on the side of the bottom, and separate the fixture body from the mounting base. Fig. 6



8. Place bollard mounting base over anchor bolts, and tighten M10 flat washer, M10 spring washer & M10\*8 nuts Fig. 7 securing the mounting base to the foundation.




Fig 7

- 9. Connect the wires, then tighten the terminal block with a flat-head screwdriver, and check to make sure all wires are in good connection Fig. 8.
- 10. Put the fixture body back on and tighten the 3 screws Fig. 9.
- 11. Installation complete.




Fig 8








**LED BOLLARD FIXTURES** 

# **INSTALLATION INSTRUCTIONS**

#### ANCHOR BOLT TEMPLATE FOR BOLLARD

Confirm dimensions before using as a template. If possible use the actual mounting plate as your template.



**ROUND** 

